

# CLEANING OF STEEL AND REMOVAL OF RUST

1490

an eight page issue

June 2007  
revision of January 2007

## DERUSTING METHODS

The effective life time of a coating applied onto a steel surface is dependent to a very large extent on how thoroughly the surface has been prepared prior to painting.

Surface preparation consists of primary surface preparation which aims to remove mill scale, rust and foreign matter from a steel surface prior to the application of a shop primer (prefabrication primer) or primer. Secondary surface preparation aims to remove rust and foreign matter, if any, from a steel surface coated with a shop primer (prefabrication primer) or primer prior to application of the anticorrosive paint system. A steel surface can be derusted in the following ways.

### Wire brushing

Wire brushing, usually done with rotating wire brushes, is a conventional method, not suitable for the removal of mill scale, but suitable for the preparation of weld seams. The main disadvantage is, that treated surfaces are often not completely free of corrosion products and tend to become polished and contaminated with oil. This decreases the adhesion of priming paints and the performance of a paint system.

### Chipping

Chipping or mechanical chipping is usually done in combination with wire-brushing. It is sometimes suitable for local repairs with conventional or special formulated paint systems. It is not suitable for general preparation of surfaces to be coated with epoxy or chlorinated rubber paints. It can be used for the removal of thick rust scale and economises in later blasting operations.

### Needle hammer

To remove rust, paint etc. from corners and angles in order to achieve a cleaned surface with a profile.

### Flame cleaning

Flame cleaning involves derusting by thermal treatment making use of burning equipment (acetylene or propane and oxygen). It removes almost all mill scale, but rust to a lesser extent. Therefore this method cannot meet the requirements of modern paint systems.

### Disc sanding

Disc sanding involves use of rotating discs covered with abrasive material. It is used for local repairs. The quality of these discs has been very much improved, and these can give good standards of preparation.

## CLEANING OF STEEL AND REMOVAL OF RUST

1490

June 2007

**Sweep blasting**

A hand operated form of superficial blast cleaning in which a primed or coated steel surface is roughened and is free of almost all visible contamination. (except oil contamination or traces of rust)

A: light sweep, purpose: roughening of intact coating and improving the adhesion of subsequent coats

Abrasive: fine (0,2-0,5 mm) is most suitable when the paint surface under treatment is not to be destroyed

B: heavy sweep (approx ISO-Sa1), purpose: removing of not sound coating areas - layers

Abrasive: small to medium (0,2-0,5/0,2-1,5 mm)

Reference: Repainting of old metallic structures, limited blast cleaning scale Technical Guide, November 1993

Laboratoire Central des Ponts et Chaussées 58,  
bd Lefebvre, F 75732 Paris Cedex 15

**Dry blast cleaning**

The impingement of a high kinetic energy stream of abrasive onto the surface to be prepared. It is either hand operated by jet or automatically by impeller and is the most thorough method of derusting. Centrifugal blast cleaning, compressed air blast cleaning and vacuum blast cleaning are well known types.

**Shot**

The particles are as far as practical spherical and solid and should not contain more than the minimum practical amount of 'tails' and irregular shapes.

Primers to be used for shot blasted steel should be checked on performance.

**Grit**

The particles show good angularity form with sharp cutting edges and should be substantially free from 'half-rounds' (i.e. shot split in half). Unless otherwise stated in the specifications a mineral grit should be used.

CLEANING OF STEEL AND REMOVAL OF RUST

1490

June 2007

**Water (abrasive) cleaning/jetting**  
(Terminology NACE)

Different types of water (abrasive) cleaning/jetting are in use  
Below you will find the most commonly used ones  
For more info see also information sheet 1498 (Hydrojetting)

**Water (abrasive) blast cleaning**

Some examples of these techniques are given below, not pretending to be complete. New developments with wet blasting methods are presented regularly, improving the efficiency and reducing the amount of water or grit.

– **LOW PRESSURE WATER ABRASIVE BLAST CLEANING**

Pressure = 6-8 bar  
Water consumption = 90-300 l/hour  
Cleaning speed = 10-16 m<sup>2</sup>/hour, depending on material to be removed

Result: a surface cleanliness and blasting profile as required can be obtained.

– **LOW PRESSURE HUMIDIFIED ABRASIVE BLAST CLEANING**

Pressure = 6-8 bar  
Water consumption = 5-60 l/hour  
Cleaning speed = 10-16 m<sup>2</sup>/hour, depending on material to be removed

Result: a surface cleanliness and blasting profile as required can be obtained.

– **ULTRA HIGH PRESSURE WATER JETTING (UHPWJ)**

Pressure - more than 1700 bar  
Use: Complete removal of all coatings and rust.  
The result can be compared with dry abrasive blast cleaning, but with flash rust after drying.  
The original blasting profile will be maintained.

– **HIGH PRESSURE WATER JETTING (HPWJ)**

Pressure - from 700 to 1700 bar  
Use: Most paints and corrosion products will be removed, Magnetite and hard tightly adherent coating may be left but can be removed with difficulty.  
The original blasting profile will be maintained.

## CLEANING OF STEEL AND REMOVAL OF RUST

1490

June 2007

**Water cleaning****– LOW PRESSURE WATER CLEANING (LPWC)**

Pressure - lower than 350 bar

Use: Removal of salt, dirt and poorly adherent surface contamination.  
Mainly washing of surface**– HIGH PRESSURE WATER CLEANING (HPWC)**

Pressure - from 350 to 700 bar

Use: Loose paint, rust, debris and material in pits will be removed, but black iron oxide (Magnetite) will remain. A uniform matte finish cannot be achieved.

**– STEAM CLEANING**

Pressure = 100-120 bar

Use: Removal of water soluble or water emulsified contamination; the substrate dries quicker compared to a water rinsed substrate.

**ISO STANDARDS**

When specifying a precise degree of derusting and cleaning of a steel surface prior to painting, Sigma uses the ISO standard ISO 8501-1-1988 and ISO 8504-1992.

**ISO 8501-1**Applicable to bare  
mill-scaled or rusty steel

This indicates the following rust grades:

- A = steel surface largely covered with adherent mill scale but little, if any, rust.
- B = steel surface which has begun to rust and from which the mill scale has begun to flake.
- C = steel surface on which the mill scale has rusted away or from which it can be scraped, but with slight pitting visible when viewed normally.
- D = steel surface on which the mill scale has rusted away and on which general pitting is visible when viewed normally.

## CLEANING OF STEEL AND REMOVAL OF RUST

1490

June 2007

**DEGREES OF PRIMARY SURFACE PREPARATION**

ISO-St Hand and power tool cleaning	<p>The ISO standard indicates six preparation degrees. The following standards are often used in specifications:</p> <p>Surface preparation by hand and power tool cleaning, such as scraping, wire-brushing, machine-brushing and grinding, is designated by the letters 'St'.</p> <p>Prior to hand and power tool cleaning, any heavy layers of rust shall be removed by chipping. Visible oil, grease and dirt shall also be removed.</p> <p>After hand and power tool cleaning, the surface shall be cleaned from loose dust and debris.</p>
ISO-St2 Thorough hand and power tool cleaning	<p>When viewed without magnification, the surface shall be free from visible oil, grease and dirt, and from poorly adhering mill scale, rust, paint coatings and foreign matter.</p>
ISO-St3 Very thorough hand and power tool cleaning	<p>As for St2, but the surface shall be treated much more thoroughly to give a metallic sheen arising from the metallic substrate.</p>
ISO-Sa Blast cleaning	<p>Surface preparation by blast cleaning is designated by the letters 'Sa'.</p> <p>Prior to blast cleaning, any heavy layers of rust shall be removed by chipping. Visible oil, grease and dirt shall also be removed.</p> <p>After blast cleaning, the surface shall be cleaned from loose dust and debris.</p>
ISO-Sa1 Light blast cleaning	<p>When viewed without magnification, the surface shall be free from visible oil, grease and dirt, and from poorly adhering mill scale, rust, paint coatings and foreign matter.</p>
ISO-Sa2 Thorough blast cleaning	<p>When viewed without magnification, the surface shall be free from visible oil, grease and dirt and from most of the mill scale, rust, paint coatings and foreign matter. Any residual contamination shall be firmly adhering.</p>
ISO-Sa2½ Very thorough blast cleaning	<p>When viewed without magnification, the surface shall be free from visible oil, grease and dirt and from mill scale, rust, paint coatings and foreign matter. Any remaining traces of contamination shall show only as slight stains in the form of spots or stripes.</p>
ISO-Sa3 blast cleaning to visually clean steel	<p>When viewed without magnification, the surface shall be free from visible oil, grease and dirt and shall be free from mill scale, rust, paint coatings and foreign matter. It shall have a uniform metallic colour.</p>

# CLEANING OF STEEL AND REMOVAL OF RUST

1490

June 2007

**Remark** The photographs in the ISO Standard publication are given as illustration only. They do not represent the complete preparation degree, which also includes a cleaning operation which is not visible in the photographs. (colourless contamination).

**Equivalents** As far as blast cleaning is concerned, equivalents according to British and American standards are given in the following table.

ISO 8501-01	BS 4232	SSPC-Vis 1 *
Sa3	1st quality	White metal SP 5
Sa2½	2nd quality	Near white SP 10
Sa2	3rd quality	Commercial SP 6

\* for more details  
see SSPC-SP.com

**Roughness of blast cleaned steel**

To specify the roughness, a variety of values is used. Such as  $R_z$ ,  $R_t$  and  $R_a$ .

$R_z$  = average peak to valley height = blasting profile

$R_t$  = maximum peak to valley height

$R_a$  = average distance to an imaginary centre line which can be drawn between peaks and valleys = C.L.A. = Centre Line Average (ISO 3274)

Normally Sigma Coatings uses  $R_z$  values.

Blasting Profile ( $R_z$ ) = 4 to 6 times C.L.A. ( $R_a$ ).

The direct measuring of the dft of primers applied onto blast cleaned steel in a thickness up to 30  $\mu\text{m}$  is very inaccurate. A primer dft of 30  $\mu\text{m}$  and more gives an average thickness and not the thickness present on the peaks.

When in the specifications blast cleaning to ISO-Sa2½ is mentioned a blasting profile  $R_z$  of 35-50  $\mu\text{m}$  should be obtained using mineral grit unless otherwise mentioned.

Above a  $R_a$  roughness of 17  $\mu\text{m}$  (= blasting profile  $R_z$  of 100  $\mu\text{m}$ ) it is recommended to use an additional coat of primer to cover the roughness.

A roughness profile above 100  $\mu\text{m}$  often results if heavily rusted steel is blast cleaned.

**JAPANESE STANDARDS**

Standard for the preparation of steel surface prior to painting SPSS-1984

These establish a systematic standard for secondary surface preparation prior to protective painting when shop primers (prefabrication primers) are used in the construction process of hull or steel structures.

CLEANING OF STEEL AND REMOVAL OF RUST

1490

June 2007

Surface condition      H = shop primed steel surface in way of hand welding  
                                   A = shop primed steel in way of automatic welding  
                                   F = shop primed steel surface in way of gas-burning  
                                   D = shop primed steel surface having white zinc salt  
                                   R = shop primed steel surface having rust in the form of spots

**GRADES OF SECONDARY SURFACE PREPARATION**

The Japanese Standard indicates six preparation degrees.  
 The following standards are often used in specifications.

SPSS-Pt2                      Surface prepared by **wire brushing** for the surface condition A, D and R, by **wire brushing** and **disc sander** for the surface condition H, by **disc sander** for the surface condition F. Almost all rust and foreign matter are fairly removed.

If mentioned for other surface conditions (e.g. primed or coated steel), almost all rust and foreign matter, have to be removed by wire brushing and/or disc sander.

SPSS-Pt3                      Surface prepared by **wire brushing** and (in combination with!) **disc sander** for the surface condition H and A and by **disc sander** for the surface condition F, R and D. Rust and foreign matter are removed to the extent that the surface has a uniform metallic sheen.

If mentioned for other surfaces conditions (e.g. primed or coated steel) all rust and foreign matter has to be removed to the extent that the surface has a uniform metallic sheen.  
 Also used for the preparation of primed or coated substrate to remove rust from small areas such as scratches, pinpoints or areas of mechanical damage.

SPSS-Ss                      Surface prepared by **light blast cleaning** of slug sands or grits. (Shop primer (prefabrication primer) with the little trace of rust is noticeable.)  
 Also used for the preparation of a primed or coated substrates or galvanized steel to roughen the surface and to remove contamination or traces of rust.

**Remarks**                      In the Japanese Standard the expressions Sd2 and Sd3 are used, which are equivalent to the Swedish expressions Sa2 and Sa3.

ISO 8501-3                      Preparation grades of welds, cut edges and other area with surface Grade P2                      imperfections.  
   See illustrations in the standard

CLEANING OF STEEL AND REMOVAL OF RUST

1490

June 2007

**Degree of cleanliness**

The ISO and the Japanese Standards give a visual impression of the quality of the derusted steel. However, chemical contamination like water soluble salts etc. are not visible and remains partly on the surface. Presence of excessive amounts of water soluble salts can cause blistering of the coating by osmosis.

**Water soluble salts in mineral abrasives.**

For tankcoatings the maximum value of water soluble salts in mineral abrasives is 250 µS/cm (conductivity) (ISO 11127-6 1993). See further sheet 1491

**Water soluble salts on the steel surface (ISO 8502-9 1998).**

Our maximum acceptable levels of water soluble salts, calculated as sodium chloride, on treated substrate prior to coating application depends on the area and expected service conditions.

	equivalent sodium chloride	conductivity (V=15 ml)
Cargo tanks	60 mg/m <sup>2</sup>	(10.0 µS/cm)
Immersed areas	80 mg/m <sup>2</sup>	(13.3 µS/cm)
Dry cargo holds	100 mg/m <sup>2</sup>	(16.7 µS/cm)

Note

Determination of water soluble salts: see information sheet 1468

**For water ballast tank areas** to be treated in accordance with **IMO resolution MSC 215(82)**: water soluble salts limit equivalent to sodium chloride after blasting/grinding must be equal to or lower than 50 mg/m<sup>2</sup> of sodium chloride.

**For areas exposed to atmosphere conditions** We recommend the limit per dry cargo holds as noted in the table. Prior to treatment the substrate should be High Pressure Washed with Fresh (clean) water.

As a guidance we recommend that the conductivity of abrasives prior to treatment should not be higher than **250 µS/cm**.

**REFERENCES**

Determination of water soluble salts according to the Bresle method (ISO 8502-6 1995)	see information sheet 1468
Specification for mineral abrasives	see information sheet 1491
Hydrojetting	see information sheet 1498

**Limitation of Liability** - The information in this data sheet is based upon laboratory tests we believe to be accurate and is intended for guidance only. All recommendations or suggestions relating to the use of the Sigma Coatings products made by SigmaKalon Marine & Protective Coatings, whether in technical documentation, or in response to a specific enquiry, or otherwise, are based on data which to the best of our knowledge are reliable. The products and information are designed for users having the requisite knowledge and industrial skills and it is the end-user's responsibility to determine the suitability of the product for its intended use.

SigmaKalon Marine & Protective Coatings has no control over either the quality or condition of the substrate, or the many factors affecting the use and application of the product. SigmaKalon Marine & Protective Coatings does therefore not accept any liability arising from loss, injury or damage resulting from such use or the contents of this data sheet (unless there are written agreements stating otherwise).

The data contained herein are liable to modification as a result of practical experience and continuous product development. This data sheet replaces and annuls all previous issues and it is therefore the user's responsibility to ensure that this sheet is current prior to using the product.